Symmetry Classification for Serial Crystallography Experiments

Groups with white backgrounds are merohedral and will exhibit indexing ambiguities. Move directly downwards to the nearest cell with a shaded background to find the corresponding "source symmetry".

Do not cross thick black lines. Chiral groups are shown in bold, centrosymmetric groups are underlined.

					t cross thick black lines. Child	6					
	Po	oint Gr	oups		Space Groups						
Triclinic l	lattice				_						
<u>1</u> 1					P1			P1			
Monoclin	ic lattice										
	2		m		P2, P2 ₁ , C2				Pm, Pc, Cm, Cc		
	<u>2/m</u>						<u>P2/</u>	m, <u>P2₁/m, C2/m, P2/c, P2</u>	2 ₁ /c, C2/c		
Orthorho	mbic lattic	e									
	222		mm2	2	P222, P222 ₁ , P2 ₁ 2 ₁ 2, P2 ₁ 2 ₁ 2 ₁ , C222 ₁ , C222, F222, I2 ₁ 2 ₁ 2 ₁			Pmm2, Pmc2 ₁ , Pcc2, Pma2, Pca2 ₁ , Pnc2, Pmn2 ₁ , Pba2, Pna2 ₁ , Pnn2, Cmm2, Cmc2 ₁ , Ccc2, Amm2, Aem2, Ama2, Aea2, Fmm2, Fdd2, Imm2, Iba2, Ima2			
			<u>mmm</u>				Pmmm, Pnnn, Pccm, Pban, Pmma, Pnna, Pmna, Pcca, Pbam, Pccn, Pbcm, Pnnm, Pmmn, Pbcn, Pbca, Pnma, Cmcm, Cmce, Cmmm, Cccm, Cmme, Ccce, Fmmm, Fddd, Immm, Ibam, Ibca, Imma				
Tetragona	al lattice										
4			<u>4/m</u>		P4, P4 ₁ , P4 ₂ , P4 ₃ , I4, I4 ₁	P4, I4				<u>P4/m, P4₂/m, P4/n,</u> <u>P4₂/n, I4/m, I4₁/a</u>	
422	42m	4m2	4mm		P422, P42 ₁ 2, P4 ₁ 22, P4 ₁ 2 ₁ 2, P4 ₂ 22, P4 ₂ 2 ₁ 2, P4 ₃ 22, P4 ₃ 2 ₁ 2, I422, I4 ₁ 22			m2, P4c2, P4b2, in2, I4m2, I4c2	P4mm, P4bm, P4 ₂ cm, P4 ₂ nm, P4cc, P4nc, P4 ₂ mc, P4 ₂ bc, I4mm, I4cm, I4 ₁ md, I4 ₁ cd		
		4,	/mmm			P4/mmm, P4/mcc, P4/nbm, P4/nnc, P4/mbm, P4/nnc, P4/nmm, P4/ncc, P4 ₂ /mmc, P4 ₂ /mcm, P4 ₂ /nbc, P4 ₂ /nbc, P4 ₂ /mbc, P4 ₂ /mnm, P4 ₂ /nmc, P4 ₂ /ncm, I4/mmm, I4/mcm, I4 ₁ /amd, I4 ₁ /acd					

Rhombohedral lattice

3	<u>3</u>		R3 (H3)	<u>R3̄ (H3̄)</u>	
32		3m	R32 (H32)		R3m (H3m), R3c (H3c)
	<u>3m</u>			<u>R3m (H3m)</u>	, <u>R3c (H3c)</u>

Hexagonal lattice

1162	3		3			P6, P6 ₁ ,		P3, P3 ₁ , P3 ₂			<u> </u>							
6			3r	3m1	3m1 6 31m		.m	6mm	P6 _E ,		P312, P32	P321, P3 ₁ 21,	P3i		ノ ト	31m, 231c	P6mm, P6cc, P6 ₃ cm,	<u>P6/m,</u> <u>P6₃/m</u>
				<u>3m1</u>	6m2	62m	<u>31m</u>			P6 ₄ , P6 ₃	P3 ₂ 12	P3 ₂ 21	<u>P3m1,</u> <u>P3c1</u>	P 6 m2, P 6 c2	P 6 2m, P 6 2c	<u>P31m,</u> <u>P31c</u>	P6 ₃ mc	_
	622		<u>6/mmm</u>					P622, P6 ₁ 22, P6 ₅ 22, P6 ₂ 22, P6 ₄ 22, P6 ₃ 22			<u>P6/mmm, P6/mcc, P6₃/mcm, P6₃/mmc</u>							

Cubic lattice

23		<u>m3</u>	P23, F23, I23, P2 ₁ 3, I2 ₁ 3		<u>Pm3</u> , <u>Pn3</u> , <u>Fm3</u> , <u>Fd3</u> , <u>Im3</u> , <u>Pa3</u> , <u>Ia3</u>
432	4 32		P432, P4 ₂ 32, F432, F4 ₁ 32, I432, P4 ₃ 32, P4 ₁ 32, I4 ₁ 32	P43m, F43m, I43m, P43n, F43c, I43d	
	m.	<u></u>			<u>Pm3m, Pn3n, Pm3n, Pn3m, Fm3m, Fm3c, Fd3m, Fd3c, Im3m, Ia3d</u>

Laue Classes

$\overline{\underline{1}}$	$\overline{1}$					
<u>2/m</u>		2	m			
<u>mmm</u>	22	22	mm2			
<u>4/m</u>		4	4			
<u>4/mmm</u>	422	42m	4m2	4mm		

<u>3</u>	3	
$\overline{3}$ m	32	3m
<u>3m1</u>	321	3m1
<u>31m</u>	312	31m

<u>6/m</u>		6	<u>-</u> 6		
<u>6/mmm</u>	622	6 m2	6 2m 6mm		
<u>m3</u>	2	23			
<u>m3m</u>	4	32	43	32	